Support / Product / VortexPro Support / Software / VectorPro

Revision ID

13123

Manual 431-483

1 VortexPro and VortexPro Touch motorised torque tester operating manual



VortexPro automated torque tester, powered by VectorPro



2 Introduction

VectorPro™ and VectorPro™ Lite are registered trademarks of PPT Group UK Ltd t/a Mecmesin.

This document refers to Mecmesin VortexPro test stands operating the latest firmware version.

It is essential that you familiarise yourself with the contents of this manual and the separate**Guide to Safe Use of Mains Powered Test Systems**' before attempting to operate your VortexPro Test System.

This reference manual covers the basic setup and operation of VortexProtest stands including VectorPro software installation.

All interlocked guarding for the VortexPro is supplied as a 'PDV' (**Product Design Variants**). This means they will be supplied as a additional item **upon special request only**. Please contact your local Mecmesin sales representative or authorised distributor for more details.

The following manuals may aid you in the use of your test stand:

- 431-398 Guide to safe use of mains powered test systems
 Covers the intial setup, installation, and safety implications for intended use of any Mecmesin supplied mains-powered equipment.
- 431-955 VectorPro User Manual Introduction and initial setup
 Covers the initial setup and installation of VectorPro test software, as well as the basics of the software functionality and user manuals. Further guidance relating to other aspects of VectorPro can be accessed through this user manual.

2.1 User manual icons

The icons shown below are used within this operating manual to identify important health and safety information as well as additional installation/operation guidance. Do not proceed until each individual message is read and thoroughly understood.

2.1.1 Warning

The **warning** icon highlights a situation or condition that may lead to possible personal injury or damage to the associated equipment.

2.1.2 Caution

The **caution** icon indicates a situation or condition that could cause the equipment to malfunction leading to possible damage.

2.1.3 Information

The **information** icon indicates additional or supplementary information about the action, activity or application.

- 1 VortexPro and VortexPro Touch motorised torque tester operating manual
- 2 Introduction
 - 2.1 User manual icons
 - 2.1.1 Warning
 - 2.1.2 Caution
 - 2.1.3 Information
- 3 Customer responsibilities
- 4 System summary
 - 4.1 Comms panel/ports
 - 4.2 System identification plate
- 5 Unpacking and parts supplied
 - 5.1 Inspection and unpacking
 - 5.2 Packaging
 - 5.3 Moving the test stand
 - 5.4 Parts supplied
 - 5.5 Accessories
- 6 Initial setup
 - 6.1 Locating the stand
 - 6.1.1 Ventilation
 - 6.1.2 Enviroment
 - 6.2 Mains power supply
 - 6.3 Earthing
 - 6.4 Fuse specification
 - 6.5 Attaching the Enhanced Torque Sensor (ETS)
 - 6.6 Fitting the Touch console (optional)
 - 6.7 Connect the test stand to a PC or Touch console
 - 6.8 Cable management
 - 6.9 Attaching grips and fixtures
 - 6.9.1 Upper fixture
 - 6.9.2 Lower fixture
 - 6.10 Test stand states
- 7 Front panel controls
 - 7.1 Emergency Stop button
 - 7.2 Multi-function scroll wheel control
 - 7.2.1 Scroll wheel colours
 - 7.2.2 Jog mode
 - 7.2.3 Navigation and selection
 - 7.2.4 Central button
 - 7.3 Display panel
 - 7.4 On-screen icons
 - 7.4.1 Pre-Test
 - 7.4.2 During a test
 - 7.4.3 Pause/Stopped
 - 7.4.4 Jog mode
 - 7.4.5 Settings menu
- 8 Settings
 - 8.1 Jog settings
 - 8.2 Units
 - 8.3 Edit test
 - 8.3.1 Cycle (by Angular Displacement)

- 8.3.2 Data capture within VectorPro™
- 8.3.3 Operation sequence and move to start
- 8.4 PIN code
- 8.5 Languages
- 8.6 Information
- 8.7 Software setup
- 8.8 Software data access
- 9 Interlock guarding overview
 - 9.1 Operating test stand without a guard fitted
 - 9.2 Operating test stand with an interlocked guard
 - 9.3 Guard closed
 - 9.4 Guard opened
 - 9.4.1 With a test running
 - 9.4.2 VortexPro without VectorPro software control
 - 9.4.3 VortexPro with VectorPro software control
- 10 Specification
- 11 Dimensions
- 12 Declaration of Conformity

3 Customer responsibilities

Where a test stand is used in conjunction with other machinery, it is the responsibility of the designer to ensure that all relevant directives and standards are complied with. Mecmesin test stands will confirm to all relevant directives and standards.

Before use, it is recommended that all operators of the machinery are given comprehensive training covering the test stand and safety measures.

Preventative safety measures prior to operation, in accordance with all relevant operator manuals, should also be considered.

4 System summary

VortexPro is a motorised torque testing systems, used for torque testing of loads up to 10 N.m.



- 1 Height adjustable crosshead
- 2 Enhanced Torque Sensor (ETS) static torque transducer
- 3 Front control panel
- 4 Emergency stop button
- 5 Top-load tray (height adjustable) for static weights
- **6** Upper fixing plate (optional shown with fixed pegs)
- 7 Lower fixing plate (optional shown with saddle plate)
- 8 Multi-function jog wheel controller

4.1 Comms panel/ports



- 1 Interlock' connection (interlock override plug shown fitted)
- 2 USB-B port (for PC or Touch console control using VectorPro™ software)
- 3 Mains connection and inlet filter (contains voltage selector and fuse holder)
- 4 System earth point

4.2 System identification plate



1	Manufacturer branding
2	Model name, eg VortexPro
3	Manufacturer address
4	Manufacturer branding
5	QR code - calibration information
6	Serial number, eg 24-1005-03
7	Voltage information
8	Conformity markings

5 Unpacking and parts supplied

5.1 Inspection and unpacking

Important! If any damage is discovered, do not proceed with the installation and contact your local supplier immediately who will decide the most appropriate action and rectify the situation as quickly as possible.

Before installing or operating the VortexPro system ensure that no visible damage has occurred during the shipping of the device

5.2 Packaging

We strongly recommend that the packaging is retained, as this can be useful if the machine needs to be returned for calibration or shipped to another location.

Parts supplied with the test stand, details the parts that should be included with your test stand. Please contact Mecmesin or your authorised distributor if any items are missing or damaged.

5.3 Moving the test stand

The unpackaged weights of the test stand is listed in the specification table. Do not try to lift heavy loads unaided. It is advised to use suitable lifting equipment and follow safe handling guidelines when moving your VortexPro system.

5.4 Parts supplied

Please see the table below for the list of parts supplied with the VortexPro test stand.

ltem	Quantity
VortexPro test stand	1
Interchangeable Enhanced Torque Sensor (ETS)	(depd on order)
VortexPro Touch console and test stand fixing bracket (optional)	(optional)
2 metre USB-A to USB-B data cable	1
M2 Allen/Hex key	1
Allen/Hex key set (2.5 mm, 3 mm, 4 mm, 5mm)	1
Mains cable pack (for UK, Europe, and USA)	1
VectorPro software key	1
Document: A Guide to Safe Use of Mecmesin Mains Powered Test Systems	1
Online Manual Information Guide	1

5.5 Accessories

For a full range of accessories, please go to the Mecmesin website (www.mecmesin.com) or contactyour local distributor.

6 Initial setup

6.1 Locating the stand

The test stand should be positioned on a suitable, level, stable work surface that can support the weight of the test stand (see specification table).

6.1.1 Ventilation

To prevent overheating, ensure that all ventilation vents on the VortexPro test stand are free from obstruction.

6.1.2 Enviroment

The VortexPro should only ever be installed in suitable environmental conditions. The operating temperature and humidity should be within the range given in the specification table.

6.2 Mains power supply

VortexPro test stands can be used on 110–120 or 220–240 V AC, 50–60 Hz supplies. The rear fuse carrier is set for your local requirement but is reversible. Should you replace a fuse, ensure the correct local voltage is selected.

The voltage that is selected is indicated by which the arrow is pointing to the white line located at the bottom of the device. This is illustrated in the image below, shown within the red circle:





6.3 Earthing

Connecting a mains powered test stand to an electrical power outlet without an earth connection is extremely dangerous and could lead to a risk of electrocution.

VortexPro test stands must be earthed. Under normal circumstances, this is done using the supplied mains power cable and most industrial mains power outlets. Please consult a qualified electrician if you are unsure of your mains power supply/outlet.

The system earth point at the rear of the test stand is solely for verifying the stand's earthing. It is not a substitute method of earthing for power supplies that are not earthed.



VortexPro system earth point

1 System earth point

6.4 Fuse specification

A VortexPro test stand uses two 2A - Time-delay (T), 5 x 20mm fuses. If replacing a blown fuse only replace the fuse on the active side of the inlet filter with the fuse specified above, or equivalent.

If you are in doubt, please contact your local Mecmesin support agent for more information.

6.5 Attaching the Enhanced Torque Sensor (ETS)

Note: Handle lower capacity torque sensors with care, as they can be damaged by mishandling.

The torque sensor attaches to the crosshead using the two supplied M6 screws.

Step 1



Align the torque sensor with the mounting plate and secure using the two 4 mm Hex screws.



If needed, have one person hold the sensor while the other fits the screws. Ensure the sensor is seated centrally before tightening the screws.

Ensure that any grips or fixtures attached to the torque sensor do not cause excessive leverage or apply excessive axial load on the sensor.

6.6 Fitting the Touch console (optional)

The Touch console and support arm can be fitted to either the left or right-hand of the test stand, but it is important to ensure that any cables from the test stand to the console are clear of any moving parts, to prevent any unnecessary kinking.

The fixing bracket can be easily fitted, adjusted or removed and transferred to the opposite column using a 4 mm Hex key to loosen the retention screws.

Sten



VortexPro - Slide console bracket down the desired column

To fit the Touch console support arm, slide the support arm bracket down the column. Depending on the required height and clearance for your application, you may need to remove the crosshead first..



VortexPro - Tighten screws in console column bracket

Pass the screws through the bracket and secure them using a 4 mm Hex key. It's recommended to have assistance during this step to support the bracket in the desired position.

Sten 3



Attach the console holder back plate to the support arm console bracket using the four crosshead screws provided, then insert the Touch console.

Step 4



Ensure the console holder front plate is unlocked using the key. Attach it to the back plate and then lock the front plate to secure your console. Adjust the angle of the arm and the orientation of the console as needed. Finally, tighten each hex screw on the support arm joints and ball-joint to secure the desired position.

6.7 Connect the test stand to a PC or Touch console

Important

VectorPro must be installed on the assigned PC (or console) before connecting the test stand to that computer.

To use VectorPro software, you must install the software before connecting your test stand to your PC (or console).

Using the provided data cable, insert the USB-B connector into the USB-B port on the rear of the test stand and the USB-A connector into an available USB-A port on your PC (or console).



The test stand will show as connected (as shown in the image to the left).

6.8 Cable management

It is essential that cables are kept free of the test stand controls and any moving parts. Failure to do so could lead to personal injury or damage to the equipment.

Ensure there are no trailing cables that could interfere with the test stand controls or the emergency stop button. All cables should be clear of any moving components.

6.9 Attaching grips and fixtures

Important! Take care not to apply excess torque on the sensor when securing the fixtures.


6.9.1 Upper fixture


The most commonly-used upper fixture used is the 100 mm upper fixing plate with a diameter capacity of 10 mm to 78 mm. This is fixed to the adaptor on the torque sensor using a 2.5 mm Hex key to secure the four countersunk screws supplied.



6.9.2 Lower fixture

The most commonly-used lower fixture is the 188 mm diameter lower fixing plate with a diameter capacity of 10 mm to 190 mm. This is fixed to the VortexPro drive spindle, using a 2.5 mm Hex key to secure the four countersunk screws supplied.





A wide range of torque testing fixtures are available, including adjustable saddle plates, extended grips, mandrels, and chucks. Go to the Mecmesin website (www.mecmesin.com) or contact your local distributor for more information.


6.10 Test stand states

The test stand can be in one of five states:

- 1. **Test readiness -** Ready to start, or complete.
- 2. **Testing -** Test operation sequence is running.
- 3. **Stopped -** Test interrupted or emergency stop pressed.
- 4. **Jog mode -** For jogging or positioning the crosshead manually.
- 5. **Settings menu -** For adjusting your test stands settings.

In each state, the selector buttons have functions described by the on-screen icons.

7 Front panel controls



_	
1	Status messages
2	Button functions
3	Multi-function selector buttons
4	Multi-function scroll wheel
5	Scroll wheel central button
6	Emergency Stop
7	Display
8	LED status indication dial

7.1 Emergency Stop button



Push to stop the crosshead movement.

Rotate the button to release it and resume crosshead control.

If pressed during a test, remove any residual load using the test stand jog controls before restarting a test

7.2 Multi-function scroll wheel control


7.2.1 Scroll wheel colours


The lights surrounding the wheel illuminate in three colours, indicating the status of the test stand:

Colour	Status	Indication
Green	Pulsating	Ready to start a test
	Rotating	Scrolling through menus
	Flashing	Test completed
Amber	Static	In jog mode menu
	Rotating	Lower spindle moving
Red	Static	Test aborted/limit triggered

7.2.2 Jog mode

In jog mode, turning the wheel drives the VortexPro clockwise or anticlockwise, corresponding to the direction of the wheel's turn. This method provides more adjustable control compared to the two fixed-speed jog control buttons (highlighted below).






- 1 Enter Jog Mode
- 2 Jog keys 'Clockwise' and 'Anti-clockwise'

The scroll wheel can function as a speed controller. The jog buttons move the spindle at preset speeds (configured in the 'Jog Settings' menu, shown below). Rotating the wheel clockwise while holding a jog button increases the speed, and rotating it anticlockwise decreases the speed.

VortexPro test stands also include a precision jog mode: rotating the scroll wheel while holding the central scroll wheel button moves the test stand at its minimum speed. This is particularly useful when fitting specimens into grips, for example.

7.2.3 Navigation and selection

The scroll wheel and central button can be used to navigate selection menus.



- 1 Confirm selection Tick selector button/scroll wheel central button
- 2 Navigate up/down menu options Up/down selector buttons/scroll wheel

Once in a selection menu the scroll wheel (2) or up/down keys (2) can cycle through the selections and values.


To confirm a selection, use either the tick selector button (1) or the scroll wheel central button (1).

The central button is used to confirm a menu selection. It is equivalent to the tick button function.

7.3 Display panel

The display indicates the stand's status, shows live values, and is used to configure the test stand's settings.

The purpose of the four multi-function buttons is indicated on-screen by adjacent icons. Below is an image illustrating a typical example of the on-screen icons corresponding to the physical buttons.



1	The top icon is 'Confirm'
2	The mid-upper icon is 'Up'
3	'Menu selection' buttons
4	The mid-lower icon is 'Down'
5	The bottom icon is 'Back/Exit'

7.4 On-screen icons

On-screen icons can vary depending on the current state of the test stand. The functions performed by the physical buttons depend on the menu currently displayed.

Below are reference tables that define the icons in relation to the test stand's state.

7.4.1 Pre-Test

	Icon	Action
		Start a test sequence
(Enable jog mode
		Go to settings
		Move to the home position (Set within VectorPro or test start position)

	Move to the nome position (Set within vector 10 or test start position)
7.4.2 During a test	
Icon	Action Pause test - This stops the lower spindle movement, leaving the stand in a state of test readiness. The status message is 'Interrupted: User' and the Play' and 'Stop' buttons will be displayed.
	Stop test - This will abort the current test running (including the VectorPro software). The status message is 'Test aborted' and the 'Home' and 'Exit' buttons will be displayed.
	Emergency stop button pushed: Message: 'Emergency Stop!!! '. Release the emergency stop to regain control and remedy the situation before resuming testing. Note there is no on-screen icon for the emergency stop.

7.4.3 Pause/Stopped

Icon Action

Continue test sequence.

Stop test - Shown when the Pause button is pressed. This ends the test at this point.

Move to the home position (start position from the beginning of the previous test) -This icon is only visible after pressing the 'Stop' button.

Exit to the test ready screen, leaving the crosshead in its current position - This icon is only visible after pressing the '**Stop**' button.

7.4.4 Jog mode

Icon Action

→0← Zero (tare) all system values.

Move the lower spindle in a clockwise direction at the set jog speed.

Move the lower spindle in a anti-clockwise direction at the set jog speed.

Go back to the previous screen.

7.4.5 Settings menu

Icon Action

Confirm selection (or press the centre scroll wheel button).

Navigate up a menu selection or value (or turn the wheel clockwise).

Navigate down a menu selection or value (or turn the wheel anticlockwise).

Go back to the previous screen.

8 Settings

8.1 Jog settings

Within the jog settings menu, you can configure the jog speed limits while in jog mode. Below is a detailed breakdown of each setting and the options available for each setting.

Setting	Action	Range
Clastavias anad	Configure the ion and in a classical direction	0.1 to 30
Clockwise speed	Configure the jog speed in a clockwise direction	rev/min
Anticlockwico cnoo	dConfigure the jog speed in an anticlockwise direction	0.1 to 30
Anticlockwise speet	acomigore the jog speed in an antictockwise direction	rev/min
Jog timeout period	Set the timeout (in minutes) that the machine will keep the motor drive engaged, before the motor drive is disabled. The load applied to the torque sensor must reach at least 25% of the sensor capacity before the timeout activation is applied. At the end of the timeout period, the 'Jog Active' menu screen is automatically switched back to the 'Ready to Test' menu screen. For example: A VortexPro stand fitted with a 6 N.m torque sensor must reach 1.5 N.m in either direction befor the timeout activation is applied. Loads below the 25% limit will not activate the timeout and the stand will actively hold the load applied.	1 to 59 minutes
Clockwise torque limit	Configure the clockwise torque limit while in jog mode.	0 to 125% torque cell capacity
Anticlockwise torque limit	Configure the anticlockwise torque limit while in jog mode.	0 to 125% torque cell capacity

8.2 Units

Within the units menu, you can configure the test stands units for displacement and speed.

Setting	Units available
Angle	rev, deg
Speed	rev/min, rev/sec, deg/min, deg/sec
Torque	N.m, N.cm, mN.m, gf.cm, kgf.cm, kgf.m, lbf.ft, lbf.in, ozf.in

8.3 Edit test

For more information relating to 'Start Direction' and 'Move to Start', please se**Operation Sequence** and **Move to Start** as well as the VectorPro software manual.

8.3.1 Cycle (by Angular Displacement)

In a cyclic test, the spindle moves between two reference angles that are relative to tared zero.

Setting	Options
Cycle count	0-9999
Clockwise speed	0-30 rev/min (0 to 180 deg/s)
Anticlockwise speed	0-30 rev/min (0 to 180 deg/s)
Clockwise angle	A positive value is clockwise from tared zero and a negative value is below
Anticlockwise angle	A positive value is clockwise from tared zero and a negative value is
Anticlockwise angle	below
Start direction	Choose whether the test direction is clockwise or anticlockwise
Move to start	Select if the test moves to the start position first

Example

- Clockwise Angle: +1000°
 Anticlockwise Angle -30°
- 3. Initial stroke: Clockwise

4. Move to Start: Yes

Unless already at -30° the spindle will first travel to that point. The stand will then move to $+100^{\circ}$ from tared zero, followed by a final movement back to -30° .

8.3.1.1

8.3.2 Data capture within VectorPro™

VectorPro manages the test configuration to control test stand operation, ensuring the speed and test orientation match your requirements. VectorPro also provides real time visualisation of results during testing. Data is stored with VectorPro's database for analysis, and can be exported to most popular formats using the built-in reporting templates, such as PDF, XLSX, CSV, TXT, HTML, and many more.

At the end of a test, or in a stopped condition, you may need to move the crosshead to clear a sample, or the drive spindle to remove residual torque.

Never restart a test from a stopped condition with a residual torque, and always Reset the gauge before a subsequent test.

For more information please refer to the Vector Pro operating manual (part no. 431-955).

Half Cycle

If the test stand is switched off or loses power during an active test, the drive spindle will stop.

A half-cycle test is to an angular displacement relative to tared zero. A cycle starts when the crosshead is at the first displacement position and ends back at the second position.

Setting	Options			
Cycle Count	0-8000			
Clockwise Speed	0-30rev/min (0 to 180 deg/s)			
Anticlockwise	2.20rs.y/min (0 to 100 dog/s)			
Speed	0-30rev/min (0 to 180 deg/s)			
Clockwise Angle	A positive value is clockwise from tared zero and a negative value is			
Clockwise Angle	below			
Anticlockwise Angle	A positive value is clockwise from tared zero and a negative value is			
Antictockwise Angle	below			
Start Direction	Choose whether the test direction is clockwise or anticlockwise			
Move to Start	Select if the test moves to the start position first			

Example

Clockwise Angle: +180°
 Anticlockwise Angle -90°
 Initial stroke: Clockwise

• Move to Start: Yes

Unless already at -90° from tared zero, the spindle will travel to that point and then move to $+180^{\circ}$ from tared zero, and stop.

8.3.3 Operation sequence and move to start

Operations, such as the half cycle consist of two datum points, a clockwise angle and anticlockwise angle.

For operations with the primary movement being clockwise, the following is true:

• The 'Anticlockwise Angle' is the start position for the test and the 'Clockwise Angle' is the finishing position.

For operations with the primary movement being anticlockwise, the following is true:

• The 'Clockwise Angle' is the start position for the test and the 'Anticlockwise Angle' is the finishing position.

Within the 'Edit Test' display on your test stands front panel there is an option called 'Move to Start', setting this feature to 'Yes' means that the stand always moves to the start position.

In some instances, this means the first direction of movement is opposite to the primary test movement. Jog settings

8.4 PIN code

Within the PIN code menu, it is possible to set a four-digit number that can be used to lock the menu feature of the test

stand. Please note once this has been set you cannot access the menu without the PIN, so it is crucial that you keep a record of this safe.

If a PIN code has been set and then lost or forgotten, please contact Mecmesin technical support or your local distributor.

8.5 Languages

Select your desired language.



Upon confirmation, you are returned to the settings menu in the language chosen.

8.6 Information



This screen is used to display vital information relating to your VortexPro and the connected ETS sensor including software, hardware, and firmware properties. You can also review calibration data for the test system.


8.7 Software setup

A VectorPro license is required to runa VortexPro test stand and VectorPro software.

VectorPro test software is supplied on a USB key or can be downloaded online from https://downloads.vectorpro.cloud

The software installation file(s) should be copied to a location from where it can be run on the operator's computer. Please do

not connect the test stand until the installation has been completed.




Step 2



VectorPro software installation
Once open, click on the **Install VectorPro'** option.

Step 3



VectorPro software installation

The VectorPro installer will install drivers necessary to complete the installation.

Step 4




VectorPro software installation

Once the associated drivers have been installed, the VectorPro software installation wizard will launch. Click**Next**' to continue and review the software license agreement.

VectorPro software installation

Before continuing the software installation, it is important that you read, understand and agree to the software license agreement in full. If you do not agree then the software installation will be terminated.

To continue, after agreeing to the license agreement, press the 'Next' button.




VectorPro software installation

Select the installation location and whether the software installs for all users (Everyone) on this computer or the current user only (Just me).

Press 'Next' to continue.

Step 7



VectorPro software installation Click 'Next' to confirm installation.

Step 8



VectorPro software installation

After installation click 'Close'.

Step 9



VectorPro software installation Click the '**Tick**' button to continue.

Step 10



VectorPro software installation

You can now choose whether to enable **Full Screen Mode**' for VectorPro.

Step 11



VectorPro software installation
Finally click the **'Off**' button to exit the installer.

8.8 Software data access

Please ensure than all Windows user accounts that launch VectorPro have Admin 'Full Control' access to the following locations:

• Default database location:

C:\ProgramData\Mecmesin\VectorPro\

• Default install location:

C:\Program Files (x86)\Mecmesin\VectorPro\

• Custom database location:

If a custom database location is specified, the Windows user must also have Admin access for this location

If you are unsure of how to perform any of the steps above, please contact your organisation's IT department for assistance.

9 Interlock guarding overview

Mecmesin test stands have the ability to generate loads large enough to cause permanent injury to human limbs when placed between the crosshead and the base. Fingers, hands and other parts of the body, or clothing, should be kept away from the moving crosshead and shroud opening.

Appropriate personal protective equipment should be worn and full local risk assessments should have been completed before use. Please refer to the supplementary documentation supplied with the Interlock guarding for full details of safety and operation.

Interlocked machine guards should be considered in all test methods as they provide additional ingress protection to the end-user. This helps to reduce the risk of injuries occurring due to contact between the test stand and the operator.

All VortexPro test stands are supplied with 'Interlock enabled', this means they are electrically and mechanically ready to use with a Mecmesin supplied guarding system.

Interlocked guarding for the VortexPro is supplied as a Product Design Variant (PDV), available as an additional item upon request.

Please contact your local Mecmesin sales representative or authorised distributor for more details.

9.1 Operating test stand without a guard fitted

It is at your discretion to operate the test system without guarding or in an un-guarded area and, if doing so, we would advise you to conduct your own risk assessment for every test and specimen.

VortexPro test stands can be operated without a supplied guard for applications that do not warrant a guard.

Test stands have an 'Override' feature that allows an interlock override plug (Part no. 351-102) supplied as an accessory to be fitted, enabling the use of a test with without a guard fitted. This plug will be supplied in the accessories and must be fitted to use the stand in normal operation.



Mecmesin interlocked guarding is fitted with a cable and plug from the guard, that must be fitted to the rear of the stand panel 'Interlock' connection, in place of the removed override plug.

When a guard is fitted and connected to the VortexPro there is no need for any menu updates or user interaction to make it functional. The stand will have certain operations and user status warnings when the guard is opened and closed.

9.3 Guard closed

With the guard door closed, normal menu displays and operations will be seen:



9.4 Guard opened

9.4.1 With a test running

The guard door should never be opened whilst a test is running. Extremely high loads and energy can be present in the machine, grips or sample under test and personal injury or damage can occur.

Allow the machine to complete the test sequence or stop the machine manually and safely remove any residual load before attempting to open the guard and access the machine, grips or sample under test.

9.4.2 VortexPro without VectorPro software control

When running a VortexPro standalone without VectorPro software control, opening the guard will result in a test being aborted and the 'Interlock Active!' status message on the front panel display:





9.4.3 VortexPro with VectorPro software control

When controlling the VortexPro test stand with VectorPro test software, the test stand front panel will behave with same actions as above.

The software will be aborted and the current test will not be recorded or stored. The software screen will briefly show the message shown below to indicate the guard had been opened during a test:

Failed

The instrument has an error or the emergency stop has been pressed


10 Specification

VortexPro									
TOLIGAL IU	N.m			ſ	0 - 10.0				
Test stand rated capacity	kgf.cm	0 - 10.0 0 - 100 0 - 90							
rest stand rated capacity	lbf.in								
	N.m	0 - 0.3	0 - 1	0 - 1.5	0 - 3.0	0 - 6.0	0 - 10.0		
Torque sensor (ETS)	kgf.cm	0 - 3	0 - 10	0 - 15	0 - 30	0 - 60	0 - 10.0		
capacity	lbf.in	0 - 2.7	0 - 9	0 - 13	0 - 26	0 - 52	0 - 90		
Position	toi.iii	0 2.7	0-2.7 0-7 0-13 0-20 0-52 0-90						
Maximum rotation		2,999 revs							
Positional accuracy				,	±0.2°				
Positional resolution					0.1°				
Speed									
Speed range	rev/min		0.1	to 30 (clockv	vise or anticlo	ckwise)			
	At steady								
Speed accuracy	state			±1% of in	dicated speed	1			
Speed resolution				0.00	1 rev/min				
Maximum number of cycles	per test				8000				
Dimensions									
Height				10)70 mm				
i ioiyiit		(max height at max elevation excluding masses)							
Width		400 mm (630 mm inc. console)							
Depth		372 mm							
Maximum travel of adjustab	le transducer	182 mm							
carriage		·							
Maximum headroom		483 mm (without fixtures)							
Width between columns		280 mm							
Weight		20 kg (23 kg inc. console)							
Static weights									
Axial load via masses on pla	ten	60 N							
· ·				(max with	a 10 Nm senso	or)			
Electrical supply				0001/:0==:		(0.11			
Voltage		230 V AC 50 Hz or 110 V AC 60 Hz							
Maximum power requiremer	nt				120W				
Torque measurement				0.507					
Torque accuracy					of full-scale	C. 16.61 11.62			
Torque units		mN.m, N.cm, N.m, kgf.cm, gf.cm, ozf.in, lbf.in, lbf.ft							
Sampling rate				Selectab	le: 10 - 1,000 H	Z			
Environment specification				100	0 0500				
Operating temperature	10°C - 35°C Normal Industry and laboratory conditions (30 - 80%), non-condensing								
Operating relative humidity		Norma	ı ındustry an	a laboratory (conditions (30	- 8U%), non-c	ondensing		
Display and data output				Land / Disci					
Front panel display indicatio	n	Load / Displacement / Speed PDF, XLSX, HTML, CSV, TXT, email and image files can all be exported from							
Output of test results	Stand	PDF, XLS	X, HTML, US\			s can all be ex	ported from		
		VectorPro software							


^{**} With upper and lower mounting tables fitted




Front view:



VortexPro - Diagram/dimensions (Front) Side view:





VortexPro - Diagram/dimensions (Top)

 $\textbf{Note:} \ \textit{VortexPro dimensions are approximate and in millimeters (mm)}.$



EU DECLARATION OF CONFORMITY

This declaration is issued under the sole responsibility of the manufacturer.

We PPT Group (UK) Ltd trading as "Mecmesin"

Of Newton House, Spring Copse Business Park, Slinfold, West Sussex. RH13 OSZ. UK

In accordance with the following EU directive(s):

Machineries Directive 2006/42/EU EMC Directive 2014/30/EU RoHS Directive 2011/65/EU

hereby declare that :

Equipment/Model Name : HelixaPro, VortexPro
Description : Universal Testing Machine

Derivative Equipment : -

Serial Number(s): All devices specified, subsequent to the date of issue of this document

is/are in conformity with the relevant Union harmonization legislation, based on conformity with the following applied harmonized standards:

 Ref. No.
 Title
 Edition/Date

 EN 61326-1
 Electrical equipment for measurement, control and laboratory use –
 2013

 EMC Requirements - General Requirements

EN 60204-1 Safety of machinery. Electrical equipment of machines - General 2018

requirements

EN 61010-1 Safety requirements for electrical equipment for measurement, 2010+A1:2019

control, and laboratory use - General requirements

Authorized Representative

Neil Pryke

Group Operations Director Date of Issue : 1st November 2023 PPT Group (UK) t/a Mecmesin PPT GmbH & Co. KG

Basler Straße 65 79100 Freiburg Deutschland

431-DoC44-01_L00

For the full declaration of conformity certificate for the VortexProclick here.

Original instructions published in English language.
© PPT Group UK Ltd t/a Mecmesin

Contact us +44 (0)1403 799979 info@mecmesin.com t/a Mecmesin Newton House Spring Copse Business Park Slinfold, West Sussex RH13 0SZ United Kingdom

PPT Group UK Ltd is a company registered in England and Wales, company number 414668.

Mecmesin is a PPT Group brand

Source URL (modified on 24/06/2024 - 09:28):https://help.mecmesin.com/docs/vortexpro-motorised-torque-tester-operating-manual