Home > HelixaPro Motorised Torque Tester Operating Manual

Support / Product / HelixaPro Support / Software / VectorPro



13182

Manual 431-484

1 HelixaPro and HelixaPro Touch motorised torque tester operating manual



HelixaPro precision automated torque tester, powered by VectorPro



# 2 Introduction

VectorPro™ and VectorPro™ Lite are registered trademarks of PPT Group UK Ltd t/a Mecmesin.

This document refers to Mecmesin HelixaPro test stands operating the latest firmware version.

It is essential that you familiarise yourself with the contents of this manual and the separate**Guide to Safe Use of Mains Powered Test Systems**' before attempting to operate your HelixaPro Test System.

This reference manual covers the basic setup and operation of HelixaProtest stands including VectorPro software installation.

All interlocked guarding for the HelixaPro is supplied as a 'PDV' (**Product Design Variants**). This means they will be supplied as a additional item **upon special request only**. Please contact your local Mecmesin sales representative or authorised distributor for more details.

The following manuals may aid you in the use of your test stand:

### 431-398 - Guide to safe use of mains powered test systems Covers the initial setup installation and safety implications for intended use of any Mecr

Covers the intial setup, installation, and safety implications for intended use of any Mecmesin supplied mains-powered equipment.

#### • 431-955 - VectorPro User Manual - Introduction and initial setup

Covers the initial setup and installation of VectorPro test software, as well as the basics of the software functionality and user manuals. Further guidance relating to other aspects of VectorPro can be accessed through this user manual.

### 2.1 User manual icons

The icons shown below are used within this operating manual to identify important health and safety information as well as additional installation/operation guidance. Do not proceed until each individual message is read and thoroughly understood.

### 2.1.1 Warning

The **warning** icon highlights a situation or condition that may lead to possible personal injury or damage to the associated equipment.

### 2.1.2 Caution

The **caution** icon indicates a situation or condition that could cause the equipment to malfunction leading to possible damage.

### 2.1.3 Information

The **information** icon indicates additional or supplementary information about the action, activity or application.

#### 1 HelixaPro and HelixaPro Touch motorised torque tester operating manual

#### 2 Introduction

- 2.1 User manual icons
  - 2.1.1 Warning
  - 2.1.2 Caution
  - 2.1.3 Information
- 3 Customer responsibilities

#### 4 System summary

- 4.1 Comms panel/ports
- 4.2 System identification plate

#### 5 Unpacking and parts supplied

- 5.1 Inspection and unpacking
- 5.2 Packaging
- 5.3 Moving the test stand
- 5.4 Parts supplied
- 5.5 Accessories

#### 6 Initial setup

- 6.1 Unpacking the stand
- 6.2 Mains power supply
- 6.3 Earthing
- 6.4 Fuse specification
- 6.5 Locating the stand
  - 6.5.1 Ventilation
  - 6.5.2 Enviroment
- 6.6 Releasing the crosshead
- 6.7 Fitting the feet/securing lugs
- 6.8 Attaching the Enhanced Torque Sensor (ETS)
- 6.9 Fitting the Touch console (optional)
- 6.10 Connect the test stand to a PC or Touch console
- 6.11 Cable management
- 6.12 Attaching grips and fixtures
  - 6.12.1 Upper fixture
  - 6.12.2 Lower fixture
- 6.13 Fitting the top mass platen
- 6.14 Counterbalance mechanism
  - 6.14.1 Integrated counterweights
    - 6.14.2 Counterbalance hanger (for additional weights)
    - 6.14.3 Applying top-load
    - 6.14.4 Securing the counterweights
- 6.15 Test stand states

#### 7 Front panel controls

- 7.1 Emergency Stop button
- 7.2 Multi-function scroll wheel control
  - 7.2.1 Scroll wheel colours
  - 7.2.2 Jog mode
  - 7.2.3 Navigation and selection
  - 7.2.4 Central button
- 7.3 Display panel
- 7.4 On-screen icons
  - 7.4.1 Pre-Test

- 7.4.2 During a test
- 7.4.3 Pause/Stopped
- 7.4.4 Jog mode
- 7.4.5 Settings menu

#### 8 Settings

- 8.1 Jog settings
- 8.2 Units
- 8.3 Edit test
  - 8.3.1 Cycle (by Angular Displacement)
  - 8.3.2 Data capture within VectorPro™
  - 8.3.3 Operation sequence and move to start
- 8.4 PIN code
- 8.5 Languages
- 8.6 Information
- 8.7 Software setup
- 8.8 Software data access
- 9 Interlock guarding overview
  - 9.1 Operating test stand without a guard fitted
  - 9.2 Operating test stand with an interlocked guard
  - 9.3 Guard closed
  - 9.4 Guard opened
    - 9.4.1 With a test running
    - 9.4.2 HelixaPro without VectorPro software control
    - 9.4.3 HelixaPro with VectorPro software control
- 10 Specification
- 11 Dimensions
- 12 Declaration of Conformity

# 3 Customer responsibilities

Where a test stand is used in conjunction with other machinery, it is the responsibility of the designer to ensure that all relevant directives and standards are complied with. Mecmesin test stands will confirm to all relevant directives and standards.

Before use, it is recommended that all operators of the machinery are given comprehensive training covering the test stand and safety measures.

Preventative safety measures prior to operation, in accordance with all relevant operator manuals, should also be considered.

# 4 System summary

HelixaPro is a motorised torque testing systems, used for torque testing of loads up to 6 N.m.



1	Height adjustable crosshead	
2	Enhanced Torque Sensor (ETS) static torque transducer	
3	Crosshead height adjustment dial	
4	Front control panel	
5	Emergency stop button	
6	Top mass platen for static weights	
7	Counterbalance hanger	
8	Upper fixture (optional - custom sample holder)	
9	Crosshead height securing lever	
10	Lower fixture (optional - custom sample holder)	
11	Multi-function jog wheel controller	

# 4.1 Comms panel/ports



1	Fuse carrier (voltage selector and fuse holder)
2	Mains power input
3	Power switch
4	System earth point (for electrical testing only)
5	Digital I/O 25-pin comms port

- 6 Vent (Do not obstruct)
- 7 Interlock' connection (interlock override plug shown fitted)
- 8 USB-B port (for PC or Touch console control using VectorPro<sup>™</sup> software)
- 9 Sensor 15-pin comms port

### 4.2 System identification plate



1	Aanufacturer branding	
2	1odel name, eg HelixaPro	
3	Manufacturer address	
4	Manufacturer branding	
5	QR code - calibration information	
6	Serial number, eg 24-1005-03	
7	Voltage information	
8	Conformity markings	

# 5 Unpacking and parts supplied

### 5.1 Inspection and unpacking

#### Important

If any damage is discovered, do not proceed with the installation and contact your local supplier immediately who will decide the most appropriate action and rectify the situation as quickly as possible.

Before installing or operating the HelixaPro system ensure that no visible damage has occurred during the shipping of the device

### 5.2 Packaging

We strongly recommend that the packaging is retained, as this can be useful if the machine needs to be returned for calibration or shipped to another location.

**Parts supplied** with the test stand, details the parts that should be included with your test stand. Please contact Mecmesin or your authorised distributor if any items are missing or damaged.

### 5.3 Moving the test stand

The unpackaged weight of the test stand is listed in the specification table. Do not try to lift heavy loads unaided. It is advised to use suitable lifting equipment and follow safe handling guidelines when moving your HelixaPro system.

### 5.4 Parts supplied

Please see the table below for the list of parts supplied with the HelixaPro test stand.

Item	Quantity
HelixaPro test stand	1
Interchangeable Enhanced Torque Sensor (ETS)	(depd on order)
Enhanced Torque Sensor (ETS) dovetail bracket and screws kit (910-432) for HelixaPro	1
HelixaPro Touch console and test stand fixing bracket (optional)	(optional)
2 metre USB-A to USB-B data cable	1
M2 hex key	1
Hex key set (2.5 mm, 3 mm, 4 mm, 5mm)	1
Mains cable pack (for UK, Europe, and USA)	1
Top mass platen and fixings	1
Balance hanger (for external weights/counter-balance)	1
Alignment tool	1
Rubber feet	4
Bench-securing lugs	4
Attachment screws (for rubber feet or bench-securing lugs)	4
VectorPro software key	1
Document: A Guide to Safe Use of Mecmesin Mains Powered Test Systems	1
Online Manual Information Guide	1

### 5.5 Accessories

For a full range of accessories, please go to the Mecmesin website (www.mecmesin.com) or contact your local distributor.

# Initial setup

6

### 6.1 Unpacking the stand

#### Important

If any damage is discovered, do not proceed with the installation and contact your local supplier immediately who will decide the most appropriate action and rectify the situation as quickly as possible.

Before installing or operating the HelixaPro system ensure that no visible damage has occurred during the shipping of the device.

We recommend that the packaging is retained for future use, such as returning the stand for calibration.

### 6.2 Mains power supply

HelixaPro test stands can be used on 110–120 or 220–240 V AC, 50–60 Hz supplies. The rear fuse carrier is set for your local requirement but is reversible. Should you replace a fuse, ensure the correct local voltage is selected.

The voltage that is selected is indicated by which the arrow is pointing to the white line, or where the two arrows align, as highlighted below. The power inlet is inverted for some test stands.



### 6.3 Earthing

Connecting a mains powered test stand to an electrical power outlet without an earth connection is extremely dangerous and could lead to a risk of electrocution.

HelixaPro test stands must be earthed. Under normal circumstances, this is done using the supplied mains power cable and most industrial mains power outlets. Please consult a qualified electrician if you are unsure of your mains power supply/outlet.

The system earth point at the rear of the test stand is solely for verifying the stand's earthing. It is not a substitute method of earthing for power supplies that are not earthed.



**1** System earth point (for verification only)

### 6.4 Fuse specification

A HelixaPro test stand uses two 2A - Time-delay (T), 5 x 20mm fuses. If replacing a blown fuse only replace the fuse on the active side of the inlet filter with the fuse specified above, or equivalent.

If you are in doubt, please contact your local Mecmesin support agent for more information.

### 6.5 Locating the stand

The test stand should be positioned on a suitable, level, stable work surface that can support the weight of the test stand (see specification table).

### 6.5.1 Ventilation

To prevent overheating, ensure that all ventilation vents on the HelixaPro test stand are free from obstruction.

### 6.5.2 Enviroment

The HelixaPro should only ever be installed in suitable environmental conditions. The operating temperature and humidity should be within the range given in the specification table.

### 6.6 Releasing the crosshead

For safety during transit the integrated counterbalance weights are secured internally (see section 'Securing the counterbalance weights' before transporting your test stand).

Ensure the securing lever to the right of the column is locked to prevent movement. Using a 4 mm hex key, as below, loosen the grew screw through the hole in the counterweights, visible at the base of the central slot.



Release the securing lever to the right of the column by a half-turn anti-clockwise. The crosshead can now be raised and lowered manually or with the height-adjustment knob to the left of the column.

Secure the crosshead position with the securing lever to the right of the column by a half-turn clockwise.

### 6.7 Fitting the feet/securing lugs

#### Warning

Do not try to lift heavy loads unaided. The unpackaged weight of the test stand is listed in the specification table.

The HelixaPro is supplied with rubber feet as standard or with bench securing lugs (optional). As a free-standing unit HelixaPro conforms to BS EN 61010-1:2010 section 7.4(a) requirements for stability.

If you will require the Touch console to be mounted higher than the mid-point of the stand column, or you are going to use additional weights in the top mass platen and/or the rear counterbalance hanger, then you will need to fit the four bench securing lugs for stability and safety.

#### Important

Handle the test stand by its base and column only. Do not hold it by the crosshead or drive spindle.



Fitting rubber feet



Carefully, lay the stand on its back, and fit the four rubber feet (or bench securing lugs) to the bottom of the stand as shown.

### 6.8 Attaching the Enhanced Torque Sensor (ETS)

**Note:** Ensure the test stand is switched off and handle lower capacity torque sensors with care, as they can be damaged by mishandling.

The Enhanced Torque Sensor (ETS) attaches to the crosshead using a dovetail bracket.







Attach the ETS dovetail bracket to the back of the sensor, using the screws provided in the kit (910-432) and a 3mm hex key.





Slide the ETS down onto the dovetail bracket at the front of the crosshead.

#### Step 3



Slide it fully downwards against the stop and tighten the securing screw using a 4mm hex key. Do not over-tighten the securing screw.



Align the electrical connector of the ETS cable with the socket on the test stand. Gently push the connector to locate, then tighten the knurled locking ring to secure it.

#### Step 5



Align the electrical connector of the ETS cable with the socket on the sensor. Gently push the connector to locate.



Ensure that any grips or fixtures attached to the torque sensor do not cause excessive leverage or apply excessive axial load on the sensor.

You can change ETS, disconnecting one sensor and fitting another, by reversing and repeating the steps above.

### 6.9 Fitting the Touch console (optional)

The Touch console and support arm can be fitted to the right-hand of the test stand, but it is important to ensure that any cables from the test stand to the console are clear of any moving parts, to prevent any unnecessary kinking.

The fixing bracket can be easily fitted, adjusted or removed without any additional tools.

#### Step





Attach the T-Slot nuts to the bolts of the support arm. The nuts should be only partially threaded on the bolt, remaining loose, and aligned vertically (as pictured).



With the T-Slot nuts aligned, insert into the T-Slot rail to the side of the test stand. It is recommended, for weight distribution, to mount the arm at the mid-point of the rail.



Tighten both upper and lower thumbscrews slowly, ensuring that the nuts have rotated one quarter-turn, for a secure grip in the rail.



With the arm secured, attach the console holder back plate to the support arm console bracket using the four crosshead screws provided, then insert the Touch console.



Step 5



Ensure the console holder front plate is unlocked using the key. Attach it to the back plate and then lock the front plate to secure your console. Adjust the angle of the arm and the orientation of the console as needed. Finally, tighten each hex screw on the support arm joints and ball-joint to secure the desired position.

### 6.10 Connect the test stand to a PC or Touch console

#### Important

VectorPro must be installed on the assigned PC (or console) before connecting the test stand to that computer.

To use VectorPro software, you must install the software before connecting your test stand to your PC (or console).

Using the provided data cable, insert the USB-B connector into the USB-B port on the rear of the test stand and the USB-A connector into an available USB-A port on your PC (or console).



The test stand will show as connected (as shown in the image to the left).

### 6.11 Cable management

It is essential that cables are kept free of the test stand controls and any moving parts. Failure to do so could lead to personal injury or damage to the equipment.

Ensure there are no trailing cables that could interfere with the test stand controls or the emergency stop button. All cables should be clear of any moving components.

### 6.12 Attaching grips and fixtures

Important! Take care not to apply excess torque on the sensor when securing the fixtures.

Grips and other fixtures are usually paired, with the lower fixture attached to the main spindle drive, and the other to the Enhanced Torque Sensor (ETS).

Fixtures on the main spindle have a self-centering fitting and four screws. The ETS has a square drive attachment.

#### 6.12.1 Upper fixture

**Important:** Low capacity sensors (ETS) are very sensitive and can be damaged easily by inadvertent overload. Take great care to engage and withdraw fixtures perpendicular to the sensor's square drive attachment without any twisting movement.

One example of an upper fixture, attached to the sensor's square drive, using a 2.5 mm hex key to tighten and secure the grub screw.







### 6.12.2 Lower fixture

One example of a lower fixture is the 100 mm diameter lower fixing plate with a diameter capacity of 20 mm to 100 mm. This is fixed to the HelixaPro drive spindle, using a 2.5 mm hex key to secure the four countersunk screws supplied.





A wide range of torque testing fixtures are available, including adjustable saddle plates, extended grips, mandrels, and chucks. Go to the Mecmesin website (www.mecmesin.com) or contact your local distributor for more information.

## 6.13 Fitting the top mass platen

#### Step



Secure the top mass platen to the top of the Enhanced Torque Sensor (ETS) using the two M6 countersunk screws supplied.

### 6.14 Counterbalance mechanism

The HelixaPro test stand crosshead is counterbalanced by a system of integrated weights. This enables the entire weight of the crosshead, Enhance Torque Sensor (ETS), and fixtures to be finely counterbalanced so that it does not interfere with torque measurements. For example, measuring the torque of a rising screw thread. Alternatively, it can be use to apply a specific downward force during torque testing by adding static weights to the top mass platen.



- 1 Top mass platen for static weights
- 2 Counterbalance hanger
- 3 Crosshead height adjustment dial
- 4 Crosshead height securing lever

The crosshead height adjustment dial (3) can be used to raise or lower the crosshead. The crosshead is fixed in place using the crosshead height securing lever (4).

### 6.14.1 Integrated counterweights

The integrated counterweight is made up of two separate weights, that can be connected or separated to apply either the whole weight (2.25 kg) or partial weight (1.5 kg).



1 Upper counterweight (1.5 kg)

2 Lower counterweight (0.75 kg)

3 Counterweight connecting screw



To adjust the counterweights in use, raise the crosshead to its highest position so that the counterweight connecting grub screw is aligned with the hole pictured above. Insert a 2 mm hex key through the hole in the back cover to either:

- **Connect** the two counterweights by tightening the connecting grub screw. This will apply the whole counterweight of 2.25 kg.
- **Disconnect** the lower counterweight by loosening the connecting grub screw until you feel the counterweights separate, by pressing down on the crosshead gently at the same time. This will apply the partial counterweight of 1.5 kg.

### 6.14.2 Counterbalance hanger (for additional weights)

An additional counterbalance hanger can be attached to the rear weight, for additional weights to be suspended. The external counterbalance hanger (3), without static masses, adds an additional 200g when attached.



Thread the counterbalance hanger screw into the upper-most counterweight hole, at the rear of the test stand.



Align the counterbalance hanger vertically and secure the bolt with an 8 mm hex key.

Additional weights/static masses can be suspended on the counterbalance hanger.

### 6.14.3 Applying top-load

The top mass platen above the moving crosshead/ETS can be used in combination with the counterweights to achieve the required balance (or load) required for testing.

Carefully place weights in the top mass platen. For guidance on using weights for top-load, please contact your local distributor or our technical support team. Excessive weight applied to the top mass platen could damage lower capacity sensors.

#### Important

The ETS contains sensitive electronics. Dropping weights into the top mass platen may cause damage to the ETS. Handle all components with care to avoid potential harm to the equipment.

### 6.14.4 Securing the counterweights

#### Warning

The integrated counterweights must be secured during transit. Failure to do so could lead to personal injury or damage to the equipment.

To secure the counterweights for transporting the test stand, ensure the crosshead height securing lever is engaged to prevent movement, then insert a 4 mm hex key to engage the grub screw through the hole in the weights. The grub screw is visible at the base of the central opening at the rear of the test stand (pictured below).



Secure the crosshead position with the securing lever to the right of the column by a half-turn clockwise.

# 6.15 Test stand states

The test stand can be in one of five states:

- 1. Test readiness Ready to start, or complete.
- 2. Testing Test operation sequence is running.
- 3. **Stopped -** Test interrupted or emergency stop pressed.
- 4. Jog mode For jogging or positioning the crosshead manually.
- 5. Settings menu For adjusting your test stands settings.

In each state, the selector buttons have functions described by the on-screen icons.





#### 1 Status messages

- 2 Button functions
- 3 Multi-function selector buttons
- 4 Multi-function scroll wheel
- Scroll wheel central button 5
- Emergency Stop 6
- 7 Display
- LED status indication dial 8

#### **Emergency Stop button** 7.1

Push to stop the crosshead movement.

Rotate the button to release it and resume crosshead control.

If pressed during a test, remove any residual load using the test stand jog controls before restarting a test

### 7.2 Multi-function scroll wheel control

### 7.2.1 Scroll wheel colours

The lights surrounding the wheel illuminate in three colours, indicating the status of the test stand:

Colour	Status	Indication
Green	Pulsating	Ready to start a test
	Rotating	Scrolling through menus
$\bigcirc$	Flashing	Test completed
Amber	Static	In jog mode menu
$\bigcirc$	Rotating	Lower spindle moving
Red		
$\bigcirc$	Static	Test aborted/limit triggered

7.2.2 Jog mode

In jog mode, turning the wheel drives the HelixaPro clockwise or anticlockwise, corresponding to the direction of the wheel's turn. This method provides more adjustable control compared to the two fixed-speed jog control buttons (highlighted below).



1	Enter Jog Mode
2	Jog keys 'Clockwise' and 'Anti-clockwise'

The scroll wheel can function as a speed controller. The jog buttons move the spindle at preset speeds (configured in the 'Jog Settings' menu, shown below). Rotating the wheel clockwise while holding a jog button increases the speed, and rotating it anticlockwise decreases the speed.

HelixaPro test stands also include a precision jog mode: rotating the scroll wheel while holding the central scroll wheel button moves the test stand at its minimum speed. This is particularly useful when fitting specimens into grips, for example.

### 7.2.3 Navigation and selection

The scroll wheel and central button can be used to navigate selection menus.



1 Confirm selection - Tick selector button/scroll wheel central button

2 Navigate up/down menu options - Up/down selector buttons/scroll wheel

Once in a selection menu the scroll wheel (2) or up/down keys (2) can cycle through the selections and values.

To confirm a selection, use either the tick selector button (1) or the scroll wheel central button (1).

The central button is used to confirm a menu selection. It is equivalent to the tick button function.

### 7.3 Display panel

The display indicates the stand's status, shows live values, and is used to configure the test stand's settings.

The purpose of the four multi-function buttons is indicated on-screen by adjacent icons. Below is an image illustrating a typical example of the on-screen icons corresponding to the physical buttons.



1	The top icon is <b>'Confirm'</b>
2	The mid-upper icon is <b>'Up'</b>
3	Menu selection' buttons
4	The mid-lower icon is <b>'Down'</b>
5	The bottom icon is 'Back/Exit'

### 7.4 On-screen icons

On-screen icons can vary depending on the current state of the test stand. The functions performed by the physical buttons depend on the menu currently displayed.

Below are reference tables that define the icons in relation to the test stand's state.

7.4.1 Pre-Test	
Icon	Action
	Start a test sequence
C	Enable jog mode
$\odot$	Go to settings
$\bigcirc$	Move to the home position (Set within VectorPro or test start position)
7.4.2 During a test	
Icon	Action
	<b>Pause test</b> - This stops the lower spindle movement, leaving the stand in a state of test readiness. The status message is <b>'Interrupted: User'</b> and the <b>'Play</b> ' and ' <b>Stop</b> ' buttons will be displayed.
	<b>Stop test</b> - This will abort the current test running (including the VectorPro software). The status message is <b>'Test aborted'</b> and the <b>'Home</b> ' and <b>'Exit</b> ' buttons will be displayed.
$\bigcirc$	<b>Emergency stop button pushed: Message: 'Emergency Stop!!!</b> '. Release the emergency stop to regain control and remedy the situation before resuming testing. Note there is no on-screen icon for the emergency stop.

7.4.3 Pause/Stopped	
lcon	Action
	Continue test sequence.
$\bigcirc$	<b>Stop test</b> - Shown when the Pause button is pressed. This ends the test at this point.
$\bigcirc$	Move to the home position (start position from the beginning of the previous test) -This icon is only visible after pressing the 'Stop' button.
<b>F</b>	Exit to the test ready screen, leaving the crosshead in its current position - This icon is only visible after pressing the 'Stop' button.
7.4.4 Jog mode	
lcon	Action
<b>→</b> 0←	Zero (tare) all system values.
C	Move the lower spindle in a clockwise direction at the set jog speed.
C	Move the lower spindle in a anti-clockwise direction at the set jog speed.
(P)	Go back to the previous screen.
7.4.5 Settings menu	
lcon	Action
$\checkmark$	Confirm selection (or press the centre scroll wheel button).
$\diamond$	Navigate up a menu selection or value (or turn the wheel clockwise).
$\checkmark$	Navigate down a menu selection or value (or turn the wheel anticlockwise).
<b>**</b>	Go back to the previous screen.



### 8.1 Jog settings

Within the jog settings menu, you can configure the jog speed limits while in jog mode. Below is a detailed breakdown of each setting and the options available for each setting.

Setting	Action	Range
Clockwise speed	Configure the jog speed in a clockwise direction	0.1 to 30
Clockwise speed		rev/min
Anticlockwise speed	Configure the jog speed in an anticlockwise direction	0.1 to 30
Anticide Kwise speet		rev/min
	Set the timeout (in minutes) that the machine will keep the motor drive engaged, before the	
	motor drive is disabled. The load applied to the torque sensor must reach at least 25% of the	
	sensor capacity before the timeout activation is applied. At the end of the timeout period, the	
	Jog Active' menu screen is automatically switched back to the 'Ready to Test' menu screen.	1 to 59
Jog timeout period	For example:	minutes
	A HelixaPro stand fitted with a 6 N.m torgue sensor must reach 1.5 N.m in either direction befor	e
	the timeout activation is applied. Loads below the 25% limit will not activate the timeout and	1
	the stand will actively hold the load applied.	
	Configure the clockwise torque limit while in jog mode.	0 to
<b>.</b>		125%
Clockwise torque		torque
limit		cell
		capacity
		0 to
	Configure the anticlockwise torque limit while in jog mode.	125%
Anticlockwise		torque
torque limit		cell
		capacity

### 8.2 Units

Within the units menu, you can configure the test stands units for displacement and speed.

Setting	Units available
Angle	rev, deg
Speed	rev/min, rev/sec, deg/min, deg/sec
Torquo	N.m, N.cm, mN.m, gf.cm, kgf.cm, kgf.m, lbf.ft, lbf.in,
Torque	ozf.in

### 8.3 Edit test

For more information relating to 'Start Direction' and 'Move to Start', please se**Operation Sequence** and **Move to Start** as well as the VectorPro software manual.

### 8.3.1 Cycle (by Angular Displacement)

In a cyclic test, the spindle moves between two reference angles that are relative to tared zero.

Setting	Options
Cycle count	0-9999
Clockwise speed	0-30 rev/min (0 to 180 deg/s)
Anticlockwise speed	0-30 rev/min (0 to 180 deg/s)
Clockwise angle	A positive value is clockwise from tared zero and a negative value is below
Anticlockwise angle	A positive value is clockwise from tared zero and a negative value is
AITLICIUCKWISE allyte	below
Start direction	Choose whether the test direction is clockwise or anticlockwise
Move to start	Select if the test moves to the start position first

#### Example

- 1. Clockwise Angle: +1000°
- 2. Anticlockwise Angle -30°
- 3. Initial stroke: Clockwise
- 4. Move to Start: Yes

Unless already at  $-30^{\circ}$  the spindle will first travel to that point. The stand will then move to  $+1000^{\circ}$  from tared zero, followed by a final movement back to  $-30^{\circ}$ .

### 8.3.1.1

### 8.3.2 Data capture within VectorPro™

VectorPro manages the test configuration to control test stand operation, ensuring the speed and test orientation match your requirements. VectorPro also provides real time visualisation of results during testing. Data is stored with VectorPro's database for analysis, and can be exported to most popular formats using the built-in reporting templates, such as PDF, XLSX, CSV, TXT, HTML, and many more.

At the end of a test, or in a stopped condition, you may need to move the crosshead to clear a sample, or the drive spindle to remove residual torque.

Never restart a test from a stopped condition with a residual torque, and always Reset the gauge before a subsequent test.

For more information please refer to the Vector Pro operating manual (part no. 431-955).

### Half Cycle

If the test stand is switched off or loses power during an active test, the drive spindle will stop.

A half-cycle test is to an angular displacement relative to tared zero. A cycle starts when the crosshead is at the first displacement position and ends back at the second position.

Setting	Options				
Cycle Count	0-8000				
Clockwise Speed	0-30rev/min (0 to 180 deg/s)				
Anticlockwise	)-30rev/min (0 to 180 deg/s)				
Speed					
Clockwise Angle	A positive value is clockwise from tared zero and a negative value is				
Clockwise Aligle	below				
Anticlockwise Angle	A positive value is clockwise from tared zero and a negative value is				
AITICIOCKWISE AITIGIE	below				
Start Direction	Choose whether the test direction is clockwise or anticlockwise				
Move to Start	Select if the test moves to the start position first				

#### Example

- Clockwise Angle: +180°
- Anticlockwise Angle -90°
- Initial stroke: Clockwise
- Move to Start: Yes

Unless already at -90° from tared zero, the spindle will travel to that point and then move to +180 from tared zero, and stop.

#### 8.3.3 Operation sequence and move to start

Operations, such as the half cycle consist of two datum points, a clockwise angle and anticlockwise angle.

For operations with the primary movement being clockwise, the following is true:

• • The 'Anticlockwise Angle' is the start position for the test and the 'Clockwise Angle' is the finishing position.

For operations with the primary movement being anticlockwise, the following is true:

• The 'Clockwise Angle' is the start position for the test and the 'Anticlockwise Angle' is the finishing position.

Within the 'Edit Test' display on your test stands front panel there is an option called 'Move to Start', setting this feature to 'Yes' means that the stand always moves to the start position.

In some instances, this means the first direction of movement is opposite to the primary test movement. Jog settings

# 8.4 PIN code

Within the PIN code menu, it is possible to set a four-digit number that can be used to lock the menu feature of the test

stand. Please note once this has been set you cannot access the menu without the PIN, so it is crucial that you keep a record of this safe.

If a PIN code has been set and then lost or forgotten, please contact Mecmesin technical support or your local distributor.

8.5 Languages

Select your desired language.



Upon confirmation, you are returned to the settings menu in the language chosen.





This screen is used to display vital information relating to your HelixaPro and the connected ETS sensor including software, hardware, and firmware properties. You can also review calibration data for the test system.

### 8.7 Software setup

A VectorPro license is required to runa HelixaPro test stand and VectorPro software.

VectorPro test software is supplied on a USB key or can be downloaded online from https://downloads.vectorpro.cloud

The software installation file(s) should be copied to a location from where it can be run on the operator's computer. Please do

not connect the test stand until the installation has been completed.



VectorPro software installation

Locate the download or installation folder and start the installation by double-clicking the/ector.Installer.exe (executable file).



VectorPro software installation Once open, click on the **Install VectorPro'** option.

	1		
Installing Micr wait.	rosoft Edge V . This may tal	VebView2 Ri ke several m	untime Ple inutes.
		0	0

VectorPro software installation

The VectorPro installer will install drivers necessary to complete the installation.

01-		
Ste	D	4



VectorPro software installation

Once the associated drivers have been installed, the VectorPro software installation wizard will launch. Click**Next'** to continue and review the software license agreement.

5		
🔉 VectorPro		- 0 X
License Agreement		- · · ×
Please take a moment to read the Agree", then "Next". Otherwise cli	license agreement now. If you accept to ick "Cancet".	he terms below, click '1
Mecmesin Software Lic Date 1st March 2022	ence Agreement	1
England (registration	t/a Mecmesin, a company inco number 00414668) having its re Lake View, Halifax, HX3 6EP,	gistered office at
O I Do Not Agree	OlAgree	
	< Back Next :	Cancel

VectorPro software installation

Before continuing the software installation, it is important that you read, understand and agree to the software license agreement in full. If you do not agree then the software installation will be terminated.

To continue, after agreeing to the license agreement, press the '**Next**' button.

6			
VectorPro	- 0 ×		
Select Installation Folder	5		
The installer will install VectorPro to the following folder. To install in this folder, click "Next". To install to a different folder.	enter it helow or click "Browne"		
The installer will install VectorPro to the following folder. To install in this folder, click "Next". To install to a different folder, Eolder.	, enter it below or click "Browse".		
To install in this folder, click "Next". To install to a different folder,	enter it below or click "Browse". Browse		
To install in this folder, click "Next". To install to a different folder, Eolder:			
To install in this folder, cick "Next". To install to a different folder, Eolder: [C:\Phogram Files (x86)/Mecmesin\VectorPio\	Browse Disk Cost		
To install in this folder, click "Next". To install to a different folder, Eolder: C:VProgram Files (v/86)/Mecmesin\VectorPro\ Install VectorPro for yourself, or for anyone who uses this comp	Browse Disk Cost		
To install in this folder, click "Next". To install to a different folder, Ecider: [C \Program Files (\d6)(Mecmesin\VectorPto\ Install VectorPto for yourself, or for anyone who uses this comp © Everyone	Browse Disk Cost		
To install in this folder, click "Next". To install to a different folder, Eolder: C:VProgram Files (v/86)/Mecmesin\VectorPro\ Install VectorPro for yourself, or for anyone who uses this comp	Browse Disk Cost		
To install in this folder, click "Next". To install to a different folder, Ecider: [C \Program Files (\d6)(Mecmesin\VectorPto\ Install VectorPto for yourself, or for anyone who uses this comp © Everyone	Browse Disk Cost		

VectorPro software installation Select the installation location and whether the software installs for all users (Everyone) on this computer or the current user only (Just me). Press '**Next**' to continue.

VectorPro		-	×
Confirm Installation			Ş
The installer is ready to install VectorPro o	n your computer.		
Click "Next" to start the installation.			

VectorPro software installation Click '**Next**' to confirm installation.

VectorPro		-		×
Installation Complete				5
VectorPro has been successfully installed.				
Click "Close" to exit.				
Please use Windows Update to check for	any critical upda	tes to the .NET Frame	work.	

VectorPro software installation After installation click **'Close**'.

	8	
The installation w	as successful.	
C		

VectorPro software installation Click the '**Tick**' button to continue.

tep 10		
	VectorPro Installer	
	Enable full screen mode?	
	0	

VectorPro software installation

You can now choose whether to enable  $\ensuremath{\textbf{Full Screen Mode}}\xspace$  for VectorPro.



VectorPro software installation Finally click the **'Off'** button to exit the installer.

# 8.8 Software data access

Please ensure than all Windows user accounts that launch VectorPro have Admin 'Full Control' access to the following locations:

- Default database location: C:\ProgramData\Mecmesin\VectorPro\
- Default install location:

C:\Program Files (x86)\Mecmesin\VectorPro\

• Custom database location:

If a custom database location is specified, the Windows user must also have Admin access for this location

If you are unsure of how to perform any of the steps above, please contact your organisation's IT department for assistance.

# 9 Interlock guarding overview

Mecmesin test stands have the ability to generate loads large enough to cause permanent injury to human limbs when placed between the crosshead and the base. Fingers, hands and other parts of the body, or clothing, should be kept away from the moving crosshead and shroud opening.

Appropriate personal protective equipment should be worn and full local risk assessments should have been completed before use. Please refer to the supplementary documentation supplied with the Interlock guarding for full details of safety and operation.

Interlocked machine guards should be considered in all test methods as they provide additional ingress protection to the end-user. This helps to reduce the risk of injuries occurring due to contact between the test stand and the operator.

All HelixaPro test stands are supplied with 'Interlock enabled', this means they are electrically and mechanically ready to use with a Mecmesin supplied guarding system.

Interlocked guarding for the HelixaPro is supplied as a Product Design Variant (PDV), available as an additional item upon request.

Please contact your local Mecmesin sales representative or authorised distributor for more details.

### 9.1 Operating test stand without a guard fitted

It is at your discretion to operate the test system without guarding or in an un-guarded area and, if doing so, we would advise you to conduct your own risk assessment for every test and specimen.

HelixaPro test stands can be operated without a supplied guard for applications that do not warrant a guard.

Test stands have an **'Override**' feature that allows an interlock override plug (Part no. 351-102) supplied as an accessory to be fitted, enabling the use of a test with without a guard fitted. This plug will be supplied in the accessories and must be fitted to use the stand in normal operation.



Mecmesin interlocked guarding is fitted with a cable and plug from the guard, that must be fitted to the rear of the stand panel '**Interlock**' connection, in place of the removed override plug.

When a guard is fitted and connected to the HelixaPro there is no need for any menu updates or user interaction to make it functional. The stand will have certain operations and user status warnings when the guard is opened and closed.

### 9.3 Guard closed

With the guard door closed, normal menu displays and operations will be seen:



# 9.4 Guard opened9.4.1 With a test running

The guard door should never be opened whilst a test is running. Extremely high loads and energy can be present in the machine, grips or sample under test and personal injury or damage can occur.

Allow the machine to complete the test sequence or stop the machine manually and safely remove any residual load before attempting to open the guard and access the machine, grips or sample under test.

### 9.4.2 HelixaPro without VectorPro software control

When running a HelixaPro standalone without VectorPro software control, opening the guard will result in a test being aborted and the '**Interlock Active!**' status message on the front panel display:





### 9.4.3 HelixaPro with VectorPro software control

When controlling the HelixaPro test stand with VectorPro test software, the test stand front panel will behave with same actions as above.

The software will be aborted and the current test will not be recorded or stored. The software screen will briefly show the message shown below to indicate the guard had been opened during a test:

# Failed The instrument has an error or the emergency stop has been pressed

10 Specification

### HelixaPro

HelixaPro										
	N.m				0 - 6					
Test stand rated capacity	kgf.cm	0 - 60								
	lbf.in	0 - 52								
	N.m	0 - 0.1	0 - 0.2	0 - 0.3	0 - 1	0 - 1.5	0 - 3	0 - 6		
Torque sensor (ETS) capacity	kgf.cm	0 - 1	0 - 2	0 - 3	0 - 10	0 - 15	0 - 30	0 - 60		
	lbf.in	0 - 0.9	0 - 1.8	0 - 2.7	0 - 9	0 - 13	0 - 26	0 - 52		
Position			•				•			
Maximum rotation				2	2,999 revs					
Positional accuracy				±0.2°						
Positional resolution				0.1°						
Speed										
Speed range	rev/min	0.1 to 30 (clockwise or anticlockwise)					e)			
Speed accuracy	At steady state			±1% of	indicated	speed				
Speed resolution				0.0	)01 rev/mii	n				
Maximum number of cycles pe	r test				8000					
Dimensions										
Height					750 mm					
Width				290 mm (58	86 mm inc	. console)				
Danath		414 mm								
Depth		(500 mm with external counterbalance hanger)								
Crosshead stroke		244 mm								
Maximum headroom		292 mm (without fixtures)								
Throat depth		112 mm								
Weight		33 kg (35 kg inc. console)								
Static weights										
					60 N					
Axial load via masses on plater	1	(max with a 6 Nm sensor)								
Axial load via masses on exterr	nal	40 N								
counterbalance hanger					40 N					
Electrical supply	-									
Voltage		230 V AC 50 Hz or 110 V AC 60 Hz								
Maximum power requirement		120W								
Torque measurement										
Torque accuracy		0.5% of full-scale								
Torque units			mN.m, N	.cm, N.m, kg	f.cm, gf.cr	m, ozf.in, lb	f.in, lbf.ft			
Sampling rate		Selectable: 10 - 1,000 Hz								
Environment specification										
Operating temperature				10	)°C - 35°C					
Operating relative humidity		Normal	Industry an	d laboratory	/ conditior	ns (30 - 80%	%), non-con	densing		
Display and data output										
Front panel display indication				Load / Dis	placemen	t / Speed				
Output of test results	Stand	PDF, XLS	X, HTML, CS	V, TXT, emai Vecto	l and imag rPro softv		all be expo	rted from		
** ****										

\*\* With upper and lower mounting tables fitted

Please note that the specifications and features described in this manual are subject to change without notice. Mecmesin reserves the right to make improvements or modifications to the product at any time, which may not be reflected in this document. For the most up-to-date information, please refer to our website or contact your local Mecmesin representative.





#### Side view:





Note: HelixaPro dimensions are approximate and in millimeters (mm).

# 12 Declaration of Conformity



			<u> </u>		
EU	DECLARA	ΑΤΙΟΝ Ο	F CONFORMITY		
This d	eclaration is is	sued under t	ne sole responsibility of the manufa	acturer.	
We	PPT Group (	UK ) Ltd tradi	ng as "Mecmesin"		
Of	Newton Ho	use, Spring Co	opse Business Park, Slinfold, West S	ussex. RH13 OSZ.	UK
In acc	ordance with	the following	EU directive(s):		
	EMC Direct	es Directive 20 tive 2014/30/ tive 2011/65/	EU		
hereb	y declare that				
	Equipment/M Description : Derivative Equ Serial Numbe	lodel Name : uipment :	HelixaPro, VortexPro Universal Testing Machine - All devices specified, subsequent to t	the date of iccus of	this document
ic /ara					
	in conformity ing applied ha		vant Union harmonization legislation ndards:	on, based on con	ionnity with the
	Ref. No.	Title			Edition/Date
	EN 61326-1		upment for measurement, control and ments - General Requirements	l laboratory use –	2013
	EN 60204-1	Safety of ma	chinery. Electrical equipment of machi	ines - General	2018
	EN 61010-1	requirement Safety requir	s rements for electrical equipment for m	easurement.	2010+A1:2019
Autho	rized Represe	ntative			
$\land$	JA	Puy	he.	PPT Group (UK) t	/a Mecmesin
Neil Grou	Pryke Ip Operations I of Issue : 1st I	Director		PPT GmbH & Co. Basler Straße 65 79100 Freiburg Deutschland	
				43	1-DoC44-01_L00

For the full declaration of conformity certificate for the HelixaPro**,click here.** 

Original instructions published in English language. © PPT Group UK Ltd t/a Mecmesin

### PPT Group UK Ltd t/a Mecmesin Newton House Spring Copse Business Park Slinfold, West Sussex RH13 0SZ United Kingdom

PPT Group UK Ltd is a company registered in England and Wales, company number 414668.

#### Mecmesin is a PPT Group brand

Source URL (modified on 30/07/2024 - 17:53):https://help.mecmesin.com/docs/helixapro-motorised-torque-tester-operating-manual